

AUX-USB 484 Compatibility Chart 20210114

Mode	Car Make	Car Model	Year
Mode 1	Mercedes-Benz NTG5.0、5.1、5.5	C180L、C200L	15-18
		C180、C200	15-18
		C200、C63	15-18
		E200L、E300、E320L	15-18
		E200、E300	15-18
		S320、S400、S450	15-18
		A180、A200、A260	15-18
		B180、B200、B260	15-18
		CLA200、CLA220、CLA260	15-18
		GLC200、GLC220、GLC260	15-18
		GLE300、GLE320	15-18
		GLS320、GLS350、GLS400	15-18
		V260	16-19
		Sprinter	12--16
	Ford	All Sync3 like Mondeo、Focus、Taurus、Edge、Kuga、Explorer3.2、Raptor	15-18
	VOLVO	S60L、S80、S90、XC90、V40、V60	14-18
		XC60、V60、V90、XC40	16-19
	PEUGEOT /Ctroen / DS	308、207、C3、C4、C5、C6、CX-3、208、408、508、4008	16-18
		5008、3008、2008、DS5、DS6	16-18
	VW/SKODA	Golf 7, Jetta 1.5, Tiguan, Lamando	16-17
		superb、Octavia、Phaeton	15-18
		Superb380	16
		Bora	19
		Magotan、Variant、Sharan、GOLF、The Beetle、Tiguan、TiguanL、Teramont	15-18
	HONDA	ACCORD 10th	18-19
		Acura CDX	16
		Civic	16
		AVANCIER	18
	TOYOTA	AVALON	19
	LEXUS	RX200T ES250	17
	Jaguar	E-PACE、I-PACE、F-PACE、XFL、XEL、XJ Coupe	15-19
	NISSAN	TEANA、Qashqai、TIIDA、X-Trail、Murano	14

	Buick	New Regal, New LaCrosse, Excelle	15-18
		Verano、Envision、Verano 4.3"	16-18
Mode 2	BMW EVO(id5/id6), MGU(id7)	1、2、3、4、5、7、X1、X2、X3、X4、X5、X7、MINI	15-19
	BMW NBT	1、2、3、4、5、7、X1、X3、X5、GT、MINI	13-16
	Mercedes-Benz MBUX (NTG 6.0)	C180L、A200、GLC260、E300	19
	Audi	A8、A7、A6、A5、A4、A3、RS6、S3、S5、Q2L、Q3、Q5、Q7、Q8	14-19
	Citroen	5008	2020
	Ford	Mondeo、Focus、Taurus、Edge、Kuga、Explorer2.2	15-18
	Buick	Verano	15-18
	Cadillac	ATSL—25T、XTS—28T	15-18
		ATSL—28T、XT5—25T、CT6—28T、XTS、CT5、XT6	
	Land Rover	Velar	16-19
	Chevrolet	Malibu XL	19
	TOYOTA	Carola	15-18
	NISSAN	Patrol	17-19
	Porsche	Cayenne B5、A231、A311、A332、Macan A151	14-
Mode 3	Land Rover	Discovery Sport,Evoque, Range Rover	16-19
Mode 4	Infiniti	M系/Q0L、Q50、Q30、QX80、QX70、QX60、QX50、QX30	17-19

	Blue LED ON	Blue LED flashes
Red LED OFF	Mode 1	Mode 2
Red LED ON	Mode 3	Mode 4

Notes:

1. Short press to switch between red LED off and red LED on
2. Long press 3 seconds to switch between blue LED on and blue LED flashes.
3. Please unplug and replug the adapter to take effect after you change mode.