

AX-ADBOX1

Solstice ^(f)	2006-2009	TOYOTA	Venza* ⁽ⁱ⁾	2009-2010
Sunfire ^(g)	2000-2005	4Runner* ⁽ⁱ⁾	Yaris* ⁽ⁱ⁾	2007-2010
SAAB		Avalon* ⁽ⁱ⁾	VOLKSWAGEN	
9-7X ^(g)	2005-2009	Camry/Camry Hybrid* ⁽ⁱ⁾	CC ^(x)	2009-up
SATURN			EOS ^(x)	2007-up
Aura ^(f)	2006-2009	Corolla* ⁽ⁱ⁾	Golf (DDIN only) ^(x)	2002
Outlook ^(e)	2007-2009	Highlander* ⁽ⁱ⁾	Golf ^(x)	2003-up
Relay ^(g)	2005-2009	Prius* ⁽ⁱ⁾	GLI ^(x)	2008-up
Sky ^(f)	2006-2009	Rav4* ⁽ⁱ⁾	GTI ^(x)	2002-up
Vue ^(e)	2008-2009	Sequoia* ⁽ⁱ⁾	Jetta (DDIN only) ^(x)	2002
SUZUKI		Sienna* ⁽ⁱ⁾	Jetta ^(x)	2003-up
XL-7 ^(e)	2007-2009	Solara* ⁽ⁱ⁾	Passat ^(x)	2002-up
		Tacoma* ⁽ⁱ⁾	Rabbit ^(x)	2007-up
		Tundra* ⁽ⁱ⁾	Tiguan ^(x)	2009-up

INSTALLATION INSTRUCTIONS**From the 16 pin harness**

- Connect the **Red** wires to the ignition/accessory wire of the aftermarket radio
- Connect the **Orange/White** wire to the illumination wire of the aftermarket radio. If the aftermarket radio does not have an illumination wire, tape off the **Orange/White** wire.
- Connect the **Blue/White** wire to the amp turn on wire of the aftermarket radio.
- Connect the **Brown** wire to the mute wire of the aftermarket radio. If the aftermarket radio does not have a Mute wire, tape up the **Brown** wire.
- For remaining wires please refer to the vehicle wiring instructions.

For aftermarket radios with navigation built-in

- Connect the **Light Green** wire to the parking brake wire of the aftermarket navigation radio.
- Connect the **Blue/Pink** wire to the V.S.S. or speed sense wire of the aftermarket navigation radio.
- Connect the **Green/Purple** wire to the reverse wire of the aftermarket navigation radio.

1-800-221-0932

metraonline.com

REV. 11/29/12 © COPYRIGHT 2004-2011 METRA ELECTRONICS CORPORATION

AX-ADBOX1**AX-ADBOX1****FEATURES**

- Provides accessory (12 volt 10 amp)
- Retains R.A.P. (Retained Accessory Power)
- Used in amplified, non-amplified systems, or digital amplified systems
- Retains chimes (GM)
- Turn signal click (GM)
- Provides NAV outputs (parking brake, reverse, mute, and V.S.S.)
- ASWC harness included (ASWC sold separately)
- Retains OnStar/OE Bluetooth
- Adjustable gain control for overall volume (on amplified systems)
- Adjustable gain control for chimes and OnStar (GM)
- Retains SYNC in Ford (if equipped)
- Adjustable gain control for SYNC (Ford)
- Retains Blind spot detection system in Chrysler/Dodge/Jeep (if equipped)
- High level speaker input
- Micro "B" USB updatable
- Retains balance and fade
- Retains digital fade

INTERFACE COMPONENTS

- AX-ADBOX1 Interface • 16-pin harness with stripped leads

TOOLS REQUIRED

- Cutting tool • Tape • Crimping tool
- Connectors (i.e. butt-connectors, bell caps, etc.)

1-800-221-0932

metraonline.com

REV. 11/29/12 © COPYRIGHT 2004-2011 METRA ELECTRONICS CORPORATION

AX-ADBOX1

Solstice ^(f)	2006-2009	TOYOTA	Venza* ⁽ⁱ⁾	2009-2010
Sunfire ^(g)	2000-2005	4Runner* ⁽ⁱ⁾	Yaris* ⁽ⁱ⁾	2007-2010
SAAB		Avalon* ⁽ⁱ⁾	VOLKSWAGEN	
9-7X ^(g)	2005-2009	Camry/Camry Hybrid* ⁽ⁱ⁾	CC ^(x)	2009-up
SATURN			EOS ^(x)	2007-up
Aura ^(f)	2006-2009	Corolla* ⁽ⁱ⁾	Golf (DDIN only) ^(x)	2002
Outlook ^(e)	2007-2009	Highlander* ⁽ⁱ⁾	Golf ^(x)	2003-up
Relay ^(g)	2005-2009	Prius* ⁽ⁱ⁾	GLI ^(x)	2008-up
Sky ^(f)	2006-2009	Rav4* ⁽ⁱ⁾	GTI ^(x)	2002-up
Vue ^(e)	2008-2009	Sequoia* ⁽ⁱ⁾	Jetta (DDIN only) ^(x)	2002
SUZUKI		Sienna* ⁽ⁱ⁾	Jetta ^(x)	2003-up
XL-7 ^(e)	2007-2009	Solara* ⁽ⁱ⁾	Passat ^(x)	2002-up
		Tacoma* ⁽ⁱ⁾	Rabbit ^(x)	2007-up
		Tundra* ⁽ⁱ⁾	Tiguan ^(x)	2009-up

INSTALLATION INSTRUCTIONS**From the 16 pin harness**

- Connect the **Red** wires to the ignition/accessory wire of the aftermarket radio
- Connect the **Orange/White** wire to the illumination wire of the aftermarket radio. If the aftermarket radio does not have an illumination wire, tape off the **Orange/White** wire.
- Connect the **Blue/White** wire to the amp turn on wire of the aftermarket radio.
- Connect the **Brown** wire to the mute wire of the aftermarket radio. If the aftermarket radio does not have a Mute wire, tape up the **Brown** wire.
- For remaining wires please refer to the vehicle wiring instructions.

For aftermarket radios with navigation built-in

- Connect the **Light Green** wire to the parking brake wire of the aftermarket navigation radio.
- Connect the **Blue/Pink** wire to the V.S.S. or speed sense wire of the aftermarket navigation radio.
- Connect the **Green/Purple** wire to the reverse wire of the aftermarket navigation radio.

1-800-221-0932

metraonline.com

REV. 11/29/12 © COPYRIGHT 2004-2011 METRA ELECTRONICS CORPORATION

AX-ADBOX1**AX-ADBOX1****FEATURES**

- Provides accessory (12 volt 10 amp)
- Retains R.A.P. (Retained Accessory Power)
- Used in amplified, non-amplified systems, or digital amplified systems
- Retains chimes (GM)
- Turn signal click (GM)
- Provides NAV outputs (parking brake, reverse, mute, and V.S.S.)
- ASWC harness included (ASWC sold separately)
- Retains OnStar/OE Bluetooth
- Adjustable gain control for overall volume (on amplified systems)
- Adjustable gain control for chimes and OnStar (GM)
- Retains SYNC in Ford (if equipped)
- Adjustable gain control for SYNC (Ford)
- Retains Blind spot detection system in Chrysler/Dodge/Jeep (if equipped)
- High level speaker input
- Micro "B" USB updatable
- Retains balance and fade
- Retains digital fade

INTERFACE COMPONENTS

- AX-ADBOX1 Interface • 16-pin harness with stripped leads

TOOLS REQUIRED

- Cutting tool • Tape • Crimping tool
- Connectors (i.e. butt-connectors, bell caps, etc.)

1-800-221-0932

metraonline.com

REV. 11/29/12 © COPYRIGHT 2004-2011 METRA ELECTRONICS CORPORATION

